

### **CODE NUMBER**

3720017

#### DESCRIPTION

1.6/1.1 gpf, Polished Chrome Finish, Single Flush, Chrome-Plated Handle, UPPERCUT® Exposed Manual Water Closet Flushometer.

#### DETAILS

• Flush Volume: 1.6/1.1 gpf (6.0/4.2 Lpf)

• Finish: Polished Chrome (CP)

• Valve: Diaphragm

• Valve Body Material: Semi-red Brass

Fixture Type: Water ClosetFixture Connection: Top spud

• Rough-In Dimension: 11 ½" (292mm)

Spud Coupling: 1 ½" (38mm)
Supply Pipe: 1" (25mm)
Handle: Chrome-Plated (CPH)

### **FEATURES**

- Lifting Handle UP initiates reduced flush (1.1 gpf/4.2 Lpf), eliminating liquid and paper waste, saving a 1/2-gallon of water
- Pushing Handle DOWN initiates full flush (1.6 gpf/6.0 Lpf), eliminating all waste
- Reduces water volume by up to 30% when activated UPWARDS
- ADA Metal Non-Hold-Open Handle with Triple Seal Handle Packing
- PERMEX® Synthetic Rubber Diaphragm with Dual Filtered Fixed Bypass
- Sweat Solder Adapter with Cover Tube & Cast Wall Flange with Set Screw
- Non-Hold-Open Handle, Fixed Metering Bypass and No External Volume Adjustment to Ensure Water Conservation
- Diaphragm, Handle Packing and Vacuum Breaker to be molded from PERMEX® Rubber Compound for Chloramine Resistance
- Includes two (2) adhesive backed Metal Wall Plates etched with Instructions



## **COMPLIANCES & CERTIFICATIONS**













(ADA Compliant, BAA Compliant, BREEAM Water Credit, cUPC Certified, cUPC Green Certified, Green Globes Water Credit)

#### RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

## **VALVE OPERATING PRESSURE (FLOWING)**

15-80 PSI (103-552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

# **DOWNLOADS**

- UPPERCUT Installation Instructions
- WES 111/115 (Spanish) Installation Instructions
- Royal Reclaimed Water Flushometer Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Reclaimed Water Flushometers Repair and Maintenance Guide
- Additional Downloads

# **NOTES**

All information contained within this document subject to change without notice.

Looking for other variations of the WES 111 product? View the general spec sheet with all options.

Find a compatible urinal for this flushometer.
Find a compatible water closet for this flushometer.



## **ROUGH-IN**

